

## PowerSeeker<sup>2</sup> 60



Item# 21028



Questions or Problems with Set-up?

CONTACT:

Celestron Technical Support: 310.803.5955

## Quick Set-up Guide



Your PowerSeeker 60 includes: optical tube; tripod with center support bracket; three eyepieces; a 3x barlow lens, finderscope and bracket; eyepiece accessory tray; telescope carrying case; accessory case; The Sky™ CD software; owner's manual.



To set up the tripod, spread the legs outward until they are fully extended and push down center locking brace.



To extend tripod legs, open each tightening clip to release the tripod leg.



Extend each of the three tripod legs down 6-8". All three legs should be the same length to provide a level platform for the telescope.



Use the three tightening clips located on each leg to secure the extended legs in place.



Place the accessory tray on top of tripod's center leg brace.



Thread the tray into the threaded hole in the center of the leg brace.



Place optical tube on mount as shown above. Line up hole on tube with the mounting screw on the tripod head.



To attach the tube to the mount, thread the screw into the mount using the threaded adapter on the bottom of the tube.

## Quick Set-up Guide [cont]



10 Locate the finderscope. Remove the rubber ring around the finderscope.



11 Slide finderscope into bracket as shown above.



12 Place the rubber ring over the eyepiece end of the finderscope. Slide ring about halfway down the finderscope tube.



13 Place mounting bracket over rubber ring and tighten set screw to secure in place.



14 The finderscope mounts onto the tube by sliding the tab on the bottom of the finderscope into the groove on the side of the optical tube.



15 Once you locate the groove on the optical tube, slide the finderscope into the groove. The finderscope should be oriented so that the large lens faces the front of the tube.



16 Pivot finderscope to desired angle and tighten locking bolt to secure in place.



17 Before attaching eyepieces to the tri-ocular holder, remove the plastic eyepiece holder caps.



18 Insert the chrome barrel of the 20mm eyepiece into the eyepiece holder.



19 Tighten set screw to secure in place. Repeat steps 18 and 19 using other two eyepieces.



20 For additional magnification, you can use the included 3x barlow. Place the barlow in the tri-ocular holder in place of any eyepiece and tighten set screw. Put desired eyepiece in barlow.



21 Remove the lens cap from the front of the telescope.



22 To observe, look through the eyepiece as shown above.



23 To change the magnification, simply rotate the tri-ocular holder so that a different eyepiece is at the top.

For detailed usage information please consult your owner's manual.